

The Quick-Start Guide





Your new Tovala has arrived, and your Tovala Meals are on the way!

Now it's time to learn the ropes, including the most important step—**connecting your Tovala to WiFi**.

What's in the box?




THE TOVALA

Your new Smart Oven! It cooks Tovala Meals, as well as your own food.




DRAIN TRAY

This slides under the front of the Tovala. It collects water that condenses from steam. Check it and empty it periodically.



WATER RESERVOIR

This is inside your Tovala. Fill it with filtered water before cooking and you'll be good to go.



RACK

This goes inside your Tovala on the lower rack level.



SHEET TRAY

This can be used to cook your own food. It should sit directly on top of the oven rack when you use it.



HOT PAD

Put it to good use by using it to grab food out of your Tovala.

What can I do with my Tovala?

A lot! You can heat and toast food. You can connect to WiFi and cook Tovala Meals. Or you can program your Tovala using the Tovala App. We'll explain how to connect to WiFi in the next section, but for now, here's a rundown of your Tovala's control panel.



TOVALA

TOAST BUTTON

The Toast setting uses a combo of wet and dry heat for breakfast-worthy toast. Press this to choose your desired toast done-ness.

HEAT BUTTON

The Heat setting switches between Broil, Steam and Convection Bake. It can heat up anything from uncooked and frozen food to leftovers without drying them out. Press this to choose your desired length of heating time.

CONTROL KNOB

Turn this to adjust the Toast and Heat settings, and press it in to start cooking. Pressing it in with nothing else selected wakes up the barcode scanner.

LIGHT SENSOR

You'll use this when you connect your Tovala to WiFi. Your smartphone's screen will flash to communicate your WiFi credentials to this sensor.

WATER LEVEL INDICATOR

These lights indicate the level of water in your water reservoir. If they're ever red, you'll need to fill up your water reservoir before cooking. The lights will turn off after 5 minutes of inactivity.

PROGRESS RING

The lights in this bar illuminate to show how far along your food is in the cooking process. A full bar means your meal is done!

WIFI INDICATOR

This indicates whether your Tovala is connected to WiFi, which it must be in order to cook a Tovala Meal or control your Tovala with the app.

online offline

BARCODE SCANNER

To scan a Tovala Meal's barcode, hold it 2 to 3 inches below the control panel and a red light will appear. If the light doesn't appear, press the control knob and the scanner will light up. The Tovala beeps when a barcode scans.

COUNTDOWN CLOCK

When you're cooking, this will display how much time is left before your food is ready.

CANCEL BUTTON

This returns your Tovala to a resting state. Press this to tell your Tovala to stop any action.



How do I connect my Tovala to WiFi?

With the Tovala App! Download it in the Apple App Store or Google Play Store, and it'll walk you through the process step by step!


Your phone will use light flashes to communicate your WiFi network's name and password to your Tovala so it can connect to our servers. Pretty cool, right?

You'll need to connect your Tovala to WiFi to cook Tovla Meals or control your Tovala with the app!

What can I do with the Tovala App?

USE OUR CHEF-CREATED PRESETS TO COOK YOUR OWN FOOD

You may not be a Tovala expert yet, but our chefs are. They built these cook cycles so you can take advantage of the Tovala's talents at the push of a button. We'll keep adding to these presets as time goes on!



MAKE YOUR OWN RECIPE

Want to do some Convection Baking? Broiling? Steaming? A little of each in sequence? Use the app to program your Tovala and prepare to bask in the glory of a meal cooked perfectly.

ORDER TOVALA MEALS

You can check what meals are available, make your picks, and even skip a week of meals or pause your subscription.

CHECK ON YOUR RECIPES

Making dinner doesn't mean you're trapped in the kitchen. Check out how much time is left and whether your Tovala is Convection Baking, Broiling or Steaming straight from the app.

GET NOTIFICATIONS

When your food is done, the Tovala App will let you know!

For a more thorough user guide, check the app's Support section.

We're keeping our manual digital so we can constantly improve it and keep it up to date.

Having trouble connecting your Tovala to WiFi?
Check and try the following:

- Make sure you're connecting to a 2.4GHz WiFi network. The Tovala isn't able to connect to 5GHz networks.
- Turn your smartphone's brightness to 80%.
- Make sure your phone's screen overlaps the small hole to the right of the Toast button. That's where the light sensor is.
- Make sure you're entering your WiFi password correctly. Typos happen to the best of us.
- All of the fields are case sensitive. Make sure you are entering uppercase and lowercase letters correctly.